

Dolphin Classic 5 / Top 5 Pool Cleaner

EN	Operating Instructions	p.	1-10
FR	Mode d'emploi	p.	11-20
IT	Istruzioni per l'uso	p.	21-30
ES	Instrucciones de uso	p.	31-40
DE	Bedienungsanleitung	s.	41-50
NL	Gebruikershandleiding	p.	51-60
PT	Instruções de operação	p.	61-70



EN

Robotic Pool Cleaner Dolphin Classic 5 / Top 5 Operating Instructions

Contents

1. INTRODUCTION	2
2. SPECIFICATIONS	2
3. WARNINGS AND CAUTIONS	2
3.1 Warnings.....	2
3.2 Cautions.....	2
4. POOL CLEANER PARTS.....	3
5. USING THE POOL CLEANER.....	4
5.1 Setup.....	4
5.2 Putting the Pool Cleaner into the pool.....	5
5.3 Removing the Pool Cleaner from the pool.....	5
5.4 Maintenance.....	6
5.5 Off-season storage	7
6. POWER SUPPLY - model Top 5 only	8
7. REMOTE CONTROL UNIT - model Top 5 only.....	9
CADDY ASSEMBLY	71

Robotic Pool Cleaner Dolphin Classic 5 / Top 5

Operating Instructions

1. INTRODUCTION

Thank you for purchasing a Maytronics Robotic Pool Cleaner.

We are sure that your Maytronics Robotic Pool Cleaner will provide you with reliable, convenient and cost effective pool cleaning. Its reliable filtration in all pool conditions and all-surface climbing brush enhance maximum pool hygiene.

The Robotic Pool Cleaners by Maytronics deliver advanced cleaning technologies, long lasting performance and easy maintenance.

2. SPECIFICATIONS

Motor protection: IP 68

Minimum depth: 0.80m/2.6ft

Maximum depth: 5m/16.4ft

3. WARNINGS AND CAUTIONS

3.1 Warnings



- Use the originally supplied power supply only
- Ensure the electrical outlet is protected by a ground fault interrupter (GFI) or an earth leakage interrupter (ELI)
- Keep the power supply out of standing water
- Position the power supply at least 3m/10ft away from the edge of the pool
- Do not enter the pool while the pool cleaner is working
- Unplug the power supply before servicing

3.2 Cautions


When not in use store the Pool Cleaner on the Caddy in a shaded area.

Use the Pool Cleaner in the following water conditions only:


Chlorine	Maximum 4 ppm
pH	7.0 - 7.8
Temperature	6 – 34°C / 43-93°F
NaCl	Maximum 5000 ppm

4. POOL CLEANER PARTS


► Robotic Pool Cleaner Model Classic 5



Robotic Pool Cleaner Model Top 5




► Brushes




Combined Brush
All surface climbing brush
ideal for most pool surfaces


Optional Brushes



PVC Brush
For concrete, PVC,
fiberglass and liner.




Wonder Brush
For smooth ceramics.




Combined Brush
All surface climbing brush
ideal for most pool surfaces

Optional Brushes





PVC Brush
For concrete, PVC,
fiberglass and liner.




Wonder Brush
For smooth ceramics.

► Power supply unit




► Filtration options


Frame Cartridges and 4 ultra-fine filters



Net filters



Bottom lid and filter Bag




5. USING THE POOL CLEANER


5.1 Set Up

Initial float set up prior to first use - Classic 5 model only

- Place cable at the right side in front of the handle.
- Float position with various type of brushes:




Attach the floating cable to the power supply by inserting it with the notch on the connector (1) lined up with the groove in the socket on the power supply and turning clockwise (2).



5.2 Putting the Pool Cleaner into the pool


If Wonder brush/ Wonder rings are dry, soak them in water until soft.

Shake the robot from side to side or turn it upside down to release trapped air. Let it sink to the pool floor.



Turn the power supply ON.




The Pool Cleaner will now operate until it has reached the end of the cleaning cycle.



5.3 Removing the Pool Cleaner from the pool

The robot will perform automatic shut-off at the end of the cleaning cycle.

 Turn OFF and unplug the power supply.



Using the floating cable, bring the Pool Cleaner to the pool's edge. Using the handle remove the Pool Cleaner from the pool.

 DO NOT PULL THE POOL CLEANER FROM THE POOL USING THE CABLE.


5.4 Maintenance

Cartridge

It is recommended to wash the cartridge after every cycle.



Filtration Options

- Ultra-fine filters for day-to-day use.
- Net filters for dirty pools with large debris such as leaves etc., useful for beginning of season.



Filter bag


Clean the filter bag with a hose.
Periodically clean the brushes with a hose.
It is recommended to periodically wash the filter bag in a washing machine.
Use gentle cycle program.



Cleaning the impeller


 **Unplug the power supply.**

If you notice debris trapped in the impeller open the impeller and remove the debris.



Cable


To remove the kinks, stretch the cable out completely and let it sit for at least a day in the sun.



5.5 Off-season storage

If the pool cleaner will not be in use for an extended period, perform the following storage steps:



- Make sure that no water is left in the pool cleaner.
- Thoroughly clean the filter bag and insert in place.
- Roll up the cable so that it has no kinks and place on the Caddy.
- Store the pool cleaner upright on the Caddy in a protected area out of direct sun/rain/frost at a temperature of between 5° - 45°C / 41° - 113°F.



6. POWER SUPPLY - MODEL TOP 5 ONLY

Digital "Switch-Mode" Power Supply with full filter bag and delay indicator.

- Input - 100-250 AC Volts
- 50-60 Hertz
- 180 Watt
- Output - <30 VDC
- IP 54



Full filter bag indicator and Reset button

The power supply is equipped with a filter bag status indicator.

The red LED indicates two filter conditions.

- When blinking - The filter is partially blocked.
- When lighted - The filter is blocked and must be emptied and cleaned.

If the LED does not turn off after the filter bag had been emptied and cleaned, press the RESET button while the robot is working.



Delay indicator

The power supply is equipped with a Delay indicator that indicates if the Delay option is activated (through the remote control unit).


7. REMOTE CONTROL UNIT - MODEL TOP 5 ONLY

The Control Panel

The remote control unit offers two operation modes – Automatic mode and manual direction control mode.

In automatic mode, the cleaning parameters can be changed.

In manual direction mode, the robot's motion can be controlled manually.



Manual Direction Control Mode

On/Off button	1. Press the On/Off button once. The remote control will start in manual direction control mode. 2. Use the direction control arrows (see right) to control the movement of the robot around the pool.	Direction control arrows
----------------------	---	---------------------------------

Exiting Manual Direction Control Mode and setting the Automatic Mode

Manual/Automatic Select button	1. To exit the manual direction control mode, press the Manual/Automatic select button once only. 2. The digital screen will light up and three rows of function icons will be displayed in default mode.	
Direction control arrows	1. To change the parameters press the up or down arrows. 2. To select the parameter settings use the right or left arrows. When you reach the required function press the Set/OK button.	Set OK button

Press the Manual/Automatic select button and then choose the desired parameters according to the following table:

 Cleaning cycle indicator This determines the length of the cleaning cycle.	 Fast 2-hour cycle	 Efficient 3-hour cycle for everyday use. (Default setting)	 Extra 4-hour cycle	
 Delay time indicator This determines when the pool cleaner starts to work. Delaying allows the dirt to settle to the bottom of the pool.	 Immediate start (Default setting)	 One-hour delay	 Two-hour delay	
 Cleaning action indicator Allowing you to choose from the following options.	 Standard Floor and wall cleaning. (Default setting)	 Ultra-clean Stronger suction and slower movement. (floor and wall)	 Floor only Cleans only the floor and the area where the floor and walls meet	 Walls only Cleans walls and waterline only

Note:

- After 2 minute if no button is pressed, the Remote Control Unit will shut-down and the Pool cleaner will continue to work in the previous settings.
- When the "Ultra-Clean" and "Walls Only" options finish their cycles, the Pool Cleaner will return to default settings.

Dolphin Classic 5 / Top 5 Pool Cleaner